



\*\*\* ATTACH ALL BOARDS WITH 3 2" NAILS AT EACH POINT  
 NAILS MUST BE COUNTERSUNK BELOW SURFACE  
 SURFACE MUST BE SCUFFED. FOR COF.